

# MAINTENANCE

## SPARK PLUGS

Refer to the Maintenance Precautions on page 108.

Recommended plugs:

Standard: DPR7EA-9 (NGK), X22EPR-U9 (NIPPONDENSO)

For E type DPR6EA-9 (NGK), X20EPR-U9 (NIPPONDENSO)

For cold climate: (Below 5°C, 41°F)

DPR6EA-9 (NGK), X20EPR-U9 (NIPPONDENSO)

For extended high speed riding:

DPR8EA-9 (NGK), X24EPR-U9 (NIPPONDENSO)

For E type DPR7EA-9 (NGK), X22EPR-U9 (NIPPONDENSO)

1. Remove the parts in sequence, according to the order in the following illustration (Left side shown; right side similar).

### Installation note:

When installing, the sequence should be the reverse order of removal: 9, 8, 7, 6, 5, 4, 3, 2 and 1

