



AUXILIARY FUNCTION

Auxiliary (AUX) Input

Use this function to listen to other audio:

Connect the input jack connector to listen to other audios.

Connect the iPod®/USB flash drive to the USB cable to operate and listen to it (see page 101).

- To turn the function on — push the AUX button. (AUX appears on the display.)
- To turn the function off — push another button.

The following functions operate the same as they do with the radio:
Switch output, Tone control, Fader control, SRS, AVC, BEEP, Muting.



AUX button

The display changes as follows each time the AUX button is pushed.

