

**iPod®/USB FLASH DRIVE**

This audio system can play the audio files on the iPod® and a USB flash drive. To play an iPod® or a USB flash drive, connect it to the USB cable in the left saddlebag (page 62).

iPod touch®, iPod®, iPod nano® are registered trademarks of Apple Inc. in the U.S. and other countries.

Use any USB flash drive and iPod® at your own risk.

Playable iPod®/USB Flash DriveCompatible Devices

iPods® and USB flash drives compatible with your audio system are:

Device	Support Requirements
USB flash drive	256 M bytes or more
Hard disk drive	Not supported
Card reader/Memory reader	Not supported
CD/DVD/FD drive	Not supported
USB hub	Not supported
iPod nano® 1st generation	F/W Ver. 1.2.0 or later
iPod nano® 2nd generation	F/W Ver. 1.1.2 or later
iPod nano® 3rd generation	F/W Ver. 1.0.0 or later
iPod nano® 4th generation	F/W Ver. 1.0.0 or later
iPod nano® 5th generation	F/W Ver. 1.0.0 or later
iPod nano® 6th generation	F/W Ver. 1.0.0 or later
iPod touch® 1st generation	F/W Ver. 1.2.0 or later
iPod touch® 2nd generation	F/W Ver. 1.0.0 or later
iPod touch® 3rd generation	F/W Ver. 4.2.0 or later

