



## MAINTENANCE

---

### Side Cover

#### Removal:

1. Open the saddlebag (page 62 ).
2. Pull the side cover out until the prongs A are clear of the frame grommets.
3. Carefully pull the side cover out until the prongs B are clear of the frame grommets.
4. Carefully remove the side cover.

#### Installation:

1. Insert the top edge of the side cover under the seat.
2. Position the side cover so the prongs on the inside of the cover are lined up above their securing grommets.
3. Push the cover in place.
4. Close the saddlebag.

#### NOTICE

Failure to use extreme care removing or installing the side covers may damage the side cover hooks.

