


Switches





 **Horn button**

 **Turn signal switch**



 **Start button**

Engine stop switch

Should normally remain in the  (Run) position.

▶ In an emergency, switch to the  (Off) position to stop the engine.

Headlight dimmer switch

- : High beam
- : Low beam