

Driver Controls

You should change drive modes only when the vehicle is stopped and the engine is idling.

NOTICE

Changing drive modes while the vehicle is moving could damage the drivetrain.

After changing the drive mode, drive several yards, making right and left turns, and make sure that indicators work properly. If the indicators do not go out or come on according to the drive mode position, see your Honda dealer.