


Cargo Bed Controls

To lower the cargo bed, make sure that the area under the front of the cargo bed is clear, then manually push down on the top of the bed rail. Check that the bed is securely lowered.



BE SURE IT IS LOCKED INTO PLACE.