


Headlight Dimmer Switch and Horn Button



Headlight Dimmer Switch


Hi— The high beam is on.

Lo— The low beam is on.

Horn Button

When the horn button is pressed the horn will sound.

Turn Signal Switch (Australia and New Zealand models only)



Move to "L" to signal a left turn, "R" to signal a right turn. Return to the center (off) when finished.