

Instruments, Controls, & Other Features

1. With the ignition switch on, press and hold the A button (▶ P. 22) for 2 seconds or more when the display function mode is odometer.
▶ The HISS indicator flashes once.
2. Turn the ignition switch off.

EC Directive

This immobilizer system complies with R & TTE (Radio and Telecommunications Terminal Equipment and the mutual recognition of their conformity) Directive.



The declaration of conformity to R & TTE Directive is provided to the owner at the time of purchase. The declaration of conformity should be kept at a safe place. When the declaration of conformity is lost or is not provided, contact your dealer.

South Africa only



Singapore only

Complies with
IDA Standards
C080226241

Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag located in the owner's manual box. ▶ P. 46

Ignition Cut-off System

A banking (lean angle) sensor automatically stops the engine and fuel pump if the motorcycle falls over. To reset the sensor, you must turn the ignition switch to OFF and back to the ON position before the engine can be restarted.