

BRAKE PAD WEAR

(See maintenance precautions on page 75).
Brake pad wear depends upon the severity of usage, the type of riding, and road conditions. Generally, the pads will wear faster on wet and dirty roads. Inspect the pads at each regular maintenance interval (page 71).

Front brake

Check the wear indicator mark (1) on each pad.

If either pad is worn to the wear indicator mark, replace both pads as a set. See your Honda dealer for this service.

NOTE:

- Only use original Honda pads or equivalent, on sale at authorized Honda dealers. When the brakes need servicing contact your Honda dealer.



(1) Wear indicator mark

