


Make sure the cut-out on the adjusting nut is seated on the brake arm pin (4) after making final free play adjustment.

REAR



- (3) Adjusting nut
- (4) Brake arm pin

- (A) Increase free play
- (B) Decrease free play

3. Apply each brake several times and check for free wheel rotation when released.

NOTE:

- * If proper adjustment cannot be obtained by this method, see your authorized Honda dealer.