

<b>(Ref.No.) Description</b>	<b>Function</b>
(20) SEL button	<p>Use this button for the following purposes.</p> <ul style="list-style-type: none"> <li>• To select the tripmeter A, tripmeter B or odometer (page 24 ).</li> <li>• To adjust time (page 26 )</li> <li>• To alter the blinking function of the immobilizer system (HISS) indicator (page 52 ).</li> </ul>
(21) RESET button	<p>Use this button for the following purposes.</p> <ul style="list-style-type: none"> <li>• To reset tripmeter (page 24 )</li> <li>• To change unit of speedometer, odometer and tripmeter (page 25 ) (E type only)</li> <li>• To adjust time (page 26 )</li> </ul>