


Initial Display

When the ignition switch is turned ON, the display will temporarily show all the modes and digital segments. Then, the speedometer (1) will show from 200 km/h to 0 km/h (E type: From 130 mph to 0 mph in mph), and the tachometer (2) will sweep to red zone again and go off. This is so that, you can make sure the liquid crystal display is functioning properly.

The unit "mph" (3) and "mile" (4) will be displayed for E type.

Digital clock (5) and tripmeter (6) will reset if the battery is disconnected.



- (1) Speedometer
- (2) Tachometer
- (3) "mph"
- (4) "mile"
- (5) Digital clock
- (6) Tripmeter