

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING (NOTE 1)				REFER TO PAGE	
			x1,000 km	1	4	8		12
			x1,000 mi	0.6	2.5	5		7.5
			MONTH		6	12		18
	TRANSMISSION OIL					R	61	
	DRIVE CHAIN		EVERY 1,000 km (600 mi) I,L				69	
	DRIVE CHAIN SLIDER						73	
	BATTERY						81	
	BRAKE FLUID	(NOTE 3)					15	
	BRAKE PADS WEAR						75	
	BRAKE SYSTEM						15, 75	
*	BRAKE LIGHT SWITCH						90	
*	HEADLIGHT AIM						-	
	CLUTCH SYSTEM						19	
	SIDE STAND						74	
*	SUSPENSION						-	
*	NUTS, BOLTS, FASTENERS						-	
**	WHEELS/TYRES						-	
**	STEERING HEAD BEARING						-	