

RIGHT CONSOLE BOX

There is a right console box (1) below the right side of the handlebar.

The maximum allowable load in the right console box and left console box shall be no more than

1.5 kg (3.3 lb).

Do not open the right console box while riding the scooter.

To Open:

- Pull the knob (2) of right console box.

To Close:

- Press forward until it is firmly closed.


Do not put the card key, mechanical key and ID tag in the right console box.

The card key system may not be activated.

Make sure the right console box is closed before riding.

When washing your scooter be careful not to flood this area with water.

Do not store valuables or fragile articles in the right console box.



(1) Right console box

(2) Knob