MAINTENANCE PRECAUTIONS (G, IIG, ND, FI)

AWARNING

- * If your motorcycle is overturned or involved in a collision, inspect control levers, cable, brake hoses, caliper, accessories, and other vital parts for damage. Do not ride the motorcycle if damage impairs safe operation. Have your authorized Honda dealer inspect the major components, including frame, suspension and steering parts, for misalignment and damage that you may not be able to detect.
- * Stop the engine and support the motorcycle securely on a firm, level surface before performing any maintenance.
- * Use new, genuine Honda parts or their equivalent for maintenance and repair. Parts which are not of equivalent quality may impair the safety of your motorcycle.

CAUTION:

* Do not use the side stand to support the motorcycle when performing maintenance; it may inadvertently retract, causing the motorcycle to fall over. Be sure to support the motorcycle securely whenever performing motorcycle maintenance.