

CONTENTS

SERIAL NUMBER LOCATION	5
CONTROL LOCATION	6
OPERATING INSTRUCTIONS	9
Speedometer/Tachometer.....	9
Main Switch	10
Emergency Switch	10
Headlight Control Switch.....	11
Horn Button.....	11
Steering Lock.....	12
Rear Shock Absorber	12
Helmet Holder	13
FUEL AND OIL	13
Fuel Valve	13
Fuel Tank.....	14
Engine Oil Recommendation	15
Viscosity	15
PRE-RIDING INSPECTION	16
STARTING THE ENGINE	16
Starting a Cold Engine.....	16
Starting in Extremely Cold Weather.....	17