


Steering Lock


The steering lock ① is located on the steering stem directly below the steering head. Turn the handle bar to the left, insert the key into the lock, turn clockwise 180° and remove the key. This locks the steering and prevents riding the motorcycle.



① Steering lock

Rear Shock Absorber

The rear shock absorber ① has five adjustment ranges and is adjusted to meet the different types of road or riding conditions. ① position is for normal riding with the damper spring strength increasing progressively from ② to ⑤; when used under heavy load conditions or when operating on bad roads.



① Rear shock absorber

② Pin spanner