


FRAME/WHEELS/BRAKES

FRONT WHEEL REMOVAL

For related torque specifications, see page 82. The numbers indicate the sequence of disassembly.



(Equipped with the ABS and TCS)

