MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 47) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

The following Maintenance Schedule specifies all naintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your authorized Honda dealer meets all of these requirements.

	FREQUENCY	WHICHEVER →		ODOMETER READING (NOTE 1)							
		COMES FIRST	×1,000 km	1	6	12	18	24	30	36	
ITEM		ţ	×1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	монтнѕ		6	12	18	24	30	36	Refer to page
*	FUEL LINE					Τ				-	
*	THROTTLE OPERATION									Ī	
*	CARBURETOR CHOKE							-		1	
	AIR CLEANER	NOTE 2					R			R	78
	SPARK PLUGS				_	R	_	R	1	R	80
*	VALVE CLEARANCE							1			
	ENGINE OIL			R		R		R		R	75
	ENGINE OIL FILTER			R		R		R		R	75
*	CARBURETOR SYNCHRONIZATION			1		1		I		1	
*	ENGINE IDLE SPEED			T	1	1	1	Ι			_
	RADIATOR COOLANT	NOTE 3				Ī		ı		R	22
*	COOLING SYSTEM		_					Ι		I	
*	SECONDARY AIR SUPPLY SYSTEM	NOTE 4				Ī		Ī		Ī	
**	TIMING BELT			EVERY 100.000 km (60.000 mi) I EVERY 150.000 km (90.000 mi) R							