

---

## SPARK PLUGS

Refer to the Safety Precautions on page 82 .

Recommended plugs:

Standard:

CR7EH-9 (NGK) or W22FER9 (DENSO)

For extended high speed riding:

CR8EH-9 (NGK) or W24FER9 (DENSO)

### NOTICE

Never use a spark plug with an improper heat range. Severe engine damage could result.

1. Remove the maintenance lid (page 89 ).
2. Remove the right and left over head cover (page 91 ).
3. Clean any dirt from around the spark plug bases.
4. Disconnect the spark plug caps. Take care to avoid damaging the spark plug wire when disconnecting the caps.
5. Using the spark plug wrench provided in the tool kit, remove the spark plugs.

