

MAINTENANCE

BRAKE PAD WEAR

Refer to the Safety Precautions on page 82 .

Brake pad wear depends upon the severity of usage, the type of riding, and road conditions. (Generally, the pads will wear faster on wet and dirty roads.)

Inspect the pads at each regular maintenance interval (page 83).


Front Brake

Always inspect each pad in both right and left brake calipers.

Check the cutout in each pad.

If either pad is worn to the cutout, replace both pads as a set. See your Honda dealer for this service.

Illustration shows left side, right side similar.



Rear Brake

Check the cutout in each pad.

If either pad is worn to the cutout, replace both pads as a set. See your Honda dealer for this service.

