
SPARK PLUGS

Refer to the Safety Precautions on page 81 .

Recommended plugs:

Standard:

CR7EH-9 (NGK) or U22FER9 (DENSO)

For extended high speed riding:

CR8EH-9 (NGK) or U24FER9 (DENSO)

NOTICE

Never use a spark plug with an improper heat range. Severe engine damage could result.

1. Remove the right and left maintenance lid (page 88).
2. Remove the right and left overhead cover (page 90).
3. Clean any dirt from around the spark plug bases.
4. Disconnect the spark plug caps. Take care to avoid damaging the spark plug wire when disconnecting the caps.
5. Using a spark plug wrench provided in the tool kit, remove the spark plugs.

