


---


## Odometer/Tripmeter

- ODO (Odometer) — Shows accumulated mileage.
- TRIP (Tripmeter) — Shows mileage per trip.



The tripmeter will show mileage in two sub modes, “tripmeter A” and “tripmeter B.”

Push the TRIP/M button to select the “tripmeter A” or “tripmeter B” mode.



To reset the tripmeter, push and hold the TRIP/M button with the display in the “tripmeter A” or “tripmeter B” mode.

