


## Fuel Drain

A fuel drain is provided to empty the carburetor and fuel tank for storage or transport.

The fuel drain is opened by turning the carburetor drain knob ① counterclockwise. If the fuel valve lever is set in the "S" position, the carburetor only will drain. With the fuel valve set in the "RES" position, all fuel in the fuel tank and carburetor will drain.

When draining fuel, place the lower end of the carburetor drain tube ② into a suitable gasoline container.

Before refilling the fuel tank, close the fuel drain by turning the carburetor drain knob clockwise until tight.



① Drain knob    ② Drain tube