

- (13) Fuel valve
- (14) Ignition switch
- (15) Horn button (U type)
- (16) Headlight dimmer switch
- (17) Headlight switch
- (18) Engine stop switch
- (19) Starter button
- (20) Choke lever
- (21) Gearshift pedal
- (22) Engine oil temperature warning lamp
- (23) Speedometer (U type)

