

Climbing hills	73
Clutch adjustment.....	111
Crossing slopes.....	82

D

Digital clock	28
Dimmer switch	21
Dipstick	34,104
Display (see Multi-function display)	24

E

Engine	
Idle speed adjustment.....	101
Break-in procedures	ii
Flooded engine.....	66
Starting the engine.....	63
Engine oil	
Changing oil.....	104
Checking oil level and adding oil.....	104
Oil filler cap/dipstick.....	34, 104
Oil high temperature indicator lamp.....	22
Recommendations	105
Engine stop switch	15
Exhaust system	
Cleaning	42
Purging.....	134

F

Final gear case oil	108
Flag pole bracket.....	35
Flooded engine	66
Fuel	
Fuel recommendations	94
Fuel fill cap.....	32, 92
Fuel tank capacity.....	92
Fuel valve.....	33
High altitude fuel mixture adjustment	103
Refueling.....	92
Reserve fuel supply.....	33
Fuse	
Location	114
Replacement.....	116