

Spark knock	90
Spark plug	105
Specifications	140
Stalling on a hill	71
Starter button	17
Storage compartment	34
Storing procedures	137

T

Throttle	
Cable	92
Lever.....	20, 92
Tires	
Inflation and air pressure	124
Repairing.....	127
Specifications	125
Tread condition	126
Tool kit.....	86
Trailer hitch	33
Trailer towing	
Operational guidelines.....	42
Weight limits.....	41
Transporting procedures.....	132
Turning	
On level ground.....	66
On slopes	79

V

Valve clearance	106
-----------------------	-----

W

Warning labels	8
Water	
Draining from brakes	122
Riding through.....	81
Weight limits	41
Wheel removal.....	123
Wiring diagram	142