

Refueling .....	88
Reserve fuel supply .....	31
<b>Fuses</b>	
Location .....	117
Replacement .....	118
<b>G</b>	
Gasoline (see Fuel)	
Gearshift pedal .....	27
Gearshifting .....	27, 63
Gear case oil .....	108
<b>H</b>	
Headlight switches .....	24
Helmet holder .....	33
High altitude carburetor adjustment .....	102
<b>Hills</b>	
Riding across slopes .....	78
Riding down hills .....	76
Riding up hills .....	69
Stopping on hills .....	71
Turning on slopes .....	79
Horn button [Australia model only] .....	18
Hourmeter [Australia model only] .....	23
<b>I</b>	
Idle speed adjustment .....	100
Ignition switch .....	14
Indicator lamps	
Neutral indicator lamp .....	26
Reverse indicator lamp .....	26
Inspection, pre-ride .....	40
<b>K</b>	
Kick starter .....	19
<b>L</b>	
Loading	
Loading guidelines and procedures .....	44
Weight limits .....	43
Lubrication (see Engine oil and Gear case oil)	