

Skidding	64
Spark arrester	132
Spark knock	86
Spark plug	106
Specifications	141
Stalling on a hill	67
Starter button	16
Starting primer knob	16
Storage compartment	31
Storing procedures	138

T

Throttle	
Cable	91
Lever	19, 91
Tires	
Inflation and air pressure	126
Repairing	129
Specifications	127
Tread condition	128
Tool kit	82
Trailer hitch	30
Trailer towing	
Operational guidelines	40
Weight limits	39
Transporting procedures	136
Turning	
On level ground	62
On slopes	75

V

Valve clearance	107
-----------------------	-----

W

Warning labels	7
Warranty service	144
Water	
Draining from brakes	124
Riding through	77
Weight limits	39
Wheel removal	125
Wiring diagram	142