

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			88, 89
*	THROTTLE OPERATION		I	I	91
*	CARBURETOR CHOKE			I	96
	AIR CLEANER	(NOTE 1)		C	92 — 94
	AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	95
	SPARK PLUG			I	108, 109
*	VALVE CLEARANCE		I	I	107
	ENGINE OIL		R	R	28, 99 — 103
	ENGINE OIL FILTER		R	R	101 — 103
*	CARBURETOR IDLE SPEED		I	I	96 — 98
	FRONT GEAR CASE OIL, REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL	YEAR I, 2 YEARS R			104 — 107
	BRAKE FLUID	(NOTE 3)		I	120, 121