

## MAINTENANCE AND REPAIRS

### MAINTENANCE SCHEDULE

		EVERY	SERVICE PERIOD		Refer to page
			INITIAL (First week of operation or 30 operating hours) (NOTE 1)	REGULAR (Every 30 days or 100 operating hours) (NOTE 1)	
I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean      R: Replace A: Adjust    L: Lubricate					
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			90, 91
*	THROTTLE OPERATION		I	I	92
*	CARBURETOR CHOKE			I	97
	AIR CLEANER	(NOTE 2)		C	93–95
	AIR CLEANER CASE DRAIN TUBE	(NOTE 3)		I	96
	SPARK PLUG			I	110, 111
*	VALVE CLEARANCE		I	I	111
	ENGINE OIL		R	R	28, 100, 101
	ENGINE OIL FILTER		R	R	102–104
*	ENGINE IDLE SPEED		I	I	97, 98
	FRONT GEAR CASE OIL, REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL	YEAR I, 2 YEARS R			106–109
*	BRAKE FLUID	(NOTE 4)		I	122–123