

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			92, 93
*	THROTTLE OPERATION		I	I	94
*	CARBURETOR CHOKE			I	99
	AIR CLEANER	(NOTE 1)		C	95–97
	AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	98
	SPARK PLUG			I	108, 109
*	VALVE CLEARANCE		I	I	109
	ENGINE OIL		R	R	32, 102–106
	ENGINE OIL FILTER		R	R	104–106
*	CARBURETOR IDLE SPEED		I	I	99–101
	FINAL DRIVE OIL	YEAR I, 2 YEARS R			107
	BRAKE FLUID	(NOTE 3)		I	121, 122