## **MAINTENANCE AND REPAIRS**

## **MAINTENANCE SCHEDULE**

		1	SERVICE PERIOD		
1			INITIAL	REGULAR	
			(First week	(Every 30	
I: Inspect and Clean, Adjust,			of	operating	
Lubricate or Replace if necessary.		EVERY	operation	days or	Refer to
C: Clean R: Replace		LVERT	or 30	100	
A: Adjust L: Lubricate			operating	operating	page
^	. Adjust E. Eubildate		hours)	hours)	
İ					
	FUEL LINE	YEARI	(NOTE 1)	(NOTE 1)	
	FUEL STRAINER SCREEN	1 11			
-		YEAR C		·	90, 91
⊢-	THROTTLE OPERATION	ļ		<u> </u>	92
*	CARBURETOR CHOKE			<u> </u>	97
	AIR CLEANER	(NOTE 2)		с	93-95
	AIR CLEANER CASE DRAIN	(NOTE 3)		1	96
	TUBE	ļ			
	SPARK PLUG	<u> </u>		<u> </u>	106, 107
*	VALVE CLEARANCE		<u> </u>	I	107
	ENGINE OIL		R	R	28,
					100, 101
	ENGINE OIL FILTER		R	R	102-104
*	ENGINE IDLE SPEED		ı	ı	97, 98
	REAR FINAL GEAR CASE OIL	YEAR I,			105
		2 YEARS R			
*	BRAKE FLUID	(NOTE 4)		ı	118, 119