## Carburetor

## **Choke Cable and Lever**

Check the condition of the choke cable (Fig. 4-9) and the operation of the choke lever (2). If the cable is damaged or kinked, have it replaced by your Honda dealer.




Fig. 4-9

(1) Choke cable

(2) Choke lever