

* A manually operated tire pump should be used rather than the high pressure systems found in service stations. This will minimize the possibility of tire damage from overinflation. If you use a high pressure system at a service station, add air in small amounts and check the pressure increase frequently to prevent possible tire damage from overinflation.

	FRONT	REAR
TIRE SIZE	AT23 × 8-11 ★★	AT25 × 11-9 ★
TIRE BRAND	ATT911 GOOD YEAR	ATT912 GOOD YEAR
RECOMMENDED PRESSURE	2.9 psi (20 kPa , 0.20 kgf/cm ²)	2.9 psi (20 kPa , 0.20 kgf/cm ²)
MAXIMUM PRESSURE	3.3 psi (23 kPa , 0.23 kgf/cm ²)	3.3 psi (23 kPa , 0.23 kgf/cm ²)
MINIMUM PRESSURE	2.5 psi (17 kPa , 0.17 kgf/cm ²)	2.5 psi (17 kPa , 0.17 kgf/cm ²)

Fig. 4-33

Tire specifications

⚠ WARNING

POTENTIAL HAZARD

Operating this ATV with improper tires, or with uneven tire pressure.

WHAT CAN HAPPEN

Use of improper tires on this ATV, or operation of this ATV with improper or uneven tire pressure, may cause loss of control, increasing your risk of an accident.

HOW TO AVOID THE HAZARD

Always use the size and type tires specified in this Owner's Manual for this vehicle.

Always maintain proper tire pressure as described in this Owner's Manual.