

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ↘	INITIAL		REGULAR		Refer to page
				MAINTENANCE	MAINTENANCE INTERVAL			
					mi	600	1200	
					km	1000	2000	
NOTE	HOURS	20	100	200				
EMISSION RELATED ITEMS	*	FUEL LINE					I	-
	*	THROTTLE OPERATION					I	98
	*	CARBURETOR CHOKE					I	103
		AIR CLEANER	(NOTE 1)			C	C	99 - 101
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	102
		SPARK PLUG				I	I	114 - 115
	*	VALVE CLEARANCE			I	J	I	115
		ENGINE OIL			R	R	R	35, 106 - 110
		ENGINE OIL FILTER			R	R	R	108 - 110
	*	ENGINE IDLE SPEED			I	I	I	104

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate