

# Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		FIRST		100	600	1200	
		⇒	mi	150	1000	2000	
		NOTE	km	20	100	200	
* FUEL LINE					I	—	
* THROTTLE OPERATION					I	117	
* CARBURETOR CHOKE					I	119	
AIR CLEANER	NOTE 1				C	112	
AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	116	
SPARK PLUG					I	123	
* VALVE CLEARANCE				I	I	126	
ENGINE OIL				R	R	103	
ENGINE OIL FILTER				R	R	107	
* ENGINE IDLE SPEED				I	I	122	

\* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 202).