

CONTENTS

	Page
MAINTENANCE AND REPAIRS	89
Emission Requirements	89
Maintenance Schedule	90
Maintenance Precautions	92
Tool Kit	93
Fuel System	94
Lubrication	106
Engine	112
Clutch	114
Electrical System	116
Brakes	123
Wheels and Tires	133
Seat Removal	138
Engine Guard and Skid Plates	139
Spark Arrester	140
TRANSPORTING YOUR FOURTRAX	142
CLEANING YOUR FOURTRAX	145
STORING YOUR FOURTRAX	147
SPECIFICATIONS	150
WIRING DIAGRAM	152
CONSUMER INFORMATION	154
WARRANTY SERVICE	156
SERIAL NUMBERS AND COLOR LABEL	157
INDEX	158
AUTHORIZED MANUALS	165