

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ⇔ NOTE	HOURS	INITIAL	REGULAR		Refer to page
				MAINT.	MAINT. INTERVAL		
				mi	600	1200	
				km	1000	2000	
	DRIVE CHAIN	NOTE 1,2		1, L	(1, LEVERY 300mi (500km) or 50 operating hours)		139
	DRIVE CHAIN SLIDER						141
*	BRAKE FLUID	NOTE 3					123
*	BRAKE PAD WEAR	NOTE 1,2					127
*	BRAKE LIGHT SWITCH						129
	BRAKE SYSTEM						123
*	REVERSE LOCK SYSTEM						109
	SKID PLATES, ENGINE GUARD						138
*	CLUTCH SYSTEM						105
*	SUSPENSION						117
*	SPARK ARRESTER				C	C	115
*	NUTS, BOLTS, FASTENERS						—
**	WHEELS/TIRES						132,173
**	TIE-ROD AND JOINT BOOTS						—
**	STEERING SHAFT HOLDER BEARINGS						—
**	STEERING SYSTEM						—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 200).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.