

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	SERVICE PERIOD		Refer to page
			INITIAL (First week of operation or 30 operating hours) (NOTE 1)	REGULAR (Every 30 operating days or 100 operating hours) (NOTE 1)	
*	FUEL LINE	YEAR 1			—
*	THROTTLE OPERATION		I	I	86
*	CARBURETOR CHOKE			I	91
	AIR CLEANER	(NOTE 2)		C	87 — 89
	AIR CLEANER HOUSING DRAIN TUBE	(NOTE 3)		I	90
	SPARK PLUG			I	102, 103
*	VALVE CLEARANCE		I	I	103
	ENGINE OIL		R	R	28, 94 — 98
	ENGINE OIL FILTER		R	R	96 — 98
*	ENGINE IDLE SPEED		I	I	91 — 93
	REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL	YEAR 1, 2 YEARS R			99 — 101
*	BRAKE FLUID	(NOTE 4)		I	116, 117