



Table of Contents

| | |
|---------------------------------------|-----------|
| Parking | 90 |
| SERVICING YOUR HONDA..... | 91 |
| <i>Before You Service Your Honda</i> | |
| The Importance of Maintenance | 93 |
| Maintenance Safety | 94 |
| Important Safety Precautions | 95 |
| Maintenance Schedule | 96 |
| Maintenance Record..... | 100 |
| <i>Service Preparations</i> | |
| Maintenance Component Locations | 101 |
| Tool Kit | 104 |
| Owner's Manual Storage..... | 105 |
| Seat Removal | 106 |
| Clip Removal | 107 |
| <i>Service Procedures</i> | |
| <u>Fluids & Filters</u> | |
| Fuel | 108 |
| Engine Oil & Filter..... | 111 |
| Gear Case Oil | 119 |
| Differential Oil..... | 121 |
| Coolant..... | 123 |
| Air Cleaner..... | 129 |
| <u>Engine</u> | |
| Throttle..... | 135 |
| Reverse Lock System..... | 137 |
| Spark Plug | 138 |
| Valves..... | 141 |
| Spark Arrester | 142 |

(cont'd)

