

## Indicators & Displays

6	Multi-function display	The display includes the following functions. <i>Display Check</i> .
	4WD indicator (Except TRX420TM1)	Shows when the 4WD drive mode engages (page 43).
	Gear position indicator	Shows the gear position (page 32).
	Speedometer	Shows riding speed (page 28).
	Fuel gauge	Shows approximate fuel supply available (page 33).
	Digital clock	Shows the time (hours and minutes) (page 35).
	Odometer	Shows accumulated mileage (page 36).
	Tripmeter	Shows mileage per trip (page 36).
	Coolant temperature gauge	Shows approximate coolant temperature (page 37).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 39).
	Maintenance minder indicator	Shows when specified maintenance interval is reached (page 40).
	Maintenance tripmeter	Inform when the mileage or operating hours on your ATV approaches and passes the interval specified on the maintenance schedule (page 40).
	Maintenance hourmeter	