

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ⇒	INITIAL MAINTENANCE		REGULAR MAINTENANCE INTERVAL		Refer to page
				mi	100	600	1200	
				km	150	1000	2000	
		NOTE	HOURS	20	100	200		
EMISSION RELATED ITEMS	*	FUEL LINE					I	—
	*	THROTTLE OPERATION					I	104
	*	CARBURETOR CHOKE					I	109
		AIR CLEANER	(NOTE 1)			C	C	105 – 107
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	108
		SPARK PLUG				I	I	120 – 121
	*	VALVE CLEARANCE			I	I	I	121
		ENGINE OIL			R	R	R	39, 112 – 116
		ENGINE OIL FILTER			R	R	R	112 – 116
	*	ENGINE IDLE SPEED			I	I	I	110

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate