

F

Final gear case oil	117
Flag pole bracket.....	40
Flooded engine	70
4WD indicator.....	21, 25
Fuel	
Fuel fill cap.....	37, 100
Fuel gauge	36
Fuel recommendations	102
Fuel tank capacity.....	100
Fuel valve.....	38
High altitude fuel mixture adjustment	111
Refueling.....	100
Reserve fuel supply.....	38
Fuses	
Location	127
Replacement, control motor fuse	127
Replacement, main fuse	127
Replacement, sub fuses	128

G

Gear change tool.....	74, 99
Gasoline (see Fuel)	
Gearshift switch	
Downshift switch	33, 71
Upshift switch	33, 71
Gearshifting.....	33, 71
Gearcase oil	
Rear final gear case oil.....	117
Gear position indicator	29

H

Headlight switches.....	21
High altitude fuel mixture adjustment.....	111
Hills	
Riding across slopes	90
Riding down hills.....	88
Riding up hills.....	81
Stopping on hills	83
Turning on slopes.....	91
Hourmeter	29