


# Controls & Features

---

## Kickstarter (TRX450R only)

RIGHT SIDE



(1) kickstarter

The kickstarter ( 1 ) is used to start the engine. To operate, swing the kickstarter out from its stored position and depress it through its entire stroke. See Starting Procedure, page 51 .