

Is Your ATV Ready to Ride?

Check these items after you get on the ATV:

Throttle Check the freeplay and adjust if needed. Press

the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions

(page 114).

Brakes Squeeze the front brake lever and step on the

rear brake pedal to check that the controls operate normally. Make sure there is no brake

fluid leakage (page 135).

Clutch Lever/

Parking Brake

Lever

Check for smooth operation and adjust if

needed (page 116).

Headlight and Headlight Dimmer

Switch

Check for proper function (page 22).

Engine Stop Switch Check for proper function (page 21).

Steering Check that the wheels turn properly as you

steer the handlebar. Move the handlebar right and left and check that there is no excessive

backlash.

Remember, be sure to take care of any problem you find, or have your Honda dealer correct it before you ride.

Before Riding