



Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, how to use the throttle and brakes, and what to do when you're through riding.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 205).

For information about carburetor adjustment for riding at high altitude, see page 206.

Safe Riding Precautions	42
Off-road Use Only	42
Keep Hands and Feet on Controls.....	43
Control Speed.....	44
Use Care on Unfamiliar or Rough Terrain.....	45
Do Not Perform Stunts.....	46
Starting & Stopping the Engine	47
Preparation	48
Starting Procedure.....	50
Flooded Engine	54
How to Stop the Engine	55
Shifting Gears	56
Braking.....	58
Riding Your ATV	60
Making Turns	60
Skidding or Sliding	62
Riding Up Hills	63
Riding Down Hills	67
Crossing or Turning on Hills or Slopes.....	68
Riding Over Obstacles	70
Riding Through Water	71
Parking	72

