

10. Install the front engine guard, the 28mm washers, and the mounting bolts. Tighten the mounting bolts.
11. Fill the oil tank with the recommended grade oil; approximately:  
5.2 US qt (4.9 ℓ , 4.3 Imp qt)
12. Reinstall the oil filler cap.
13. Start the engine and let it idle for 5 minutes.
14. Stop the engine and after a few minutes, remove the oil filler cap and dipstick.
15. Add the recommended oil up to the upper level mark. (Do not overfill.)
16. Reinstall the oil filler cap and dipstick.
17. Check for oil leaks.

**CAUTION:**

**Running the engine with improper oil level can cause serious engine damage.**

**NOTE:**

- \* To protect the environment, please dispose of used engine oil properly. We suggest you place used oil in a sealed container and take it to your local service station for reclamation. Do not put it in the trash or pour it on the ground.
- \* If a torque wrench was not used for installation, see your authorized Honda dealer before operating the vehicle to verify proper assembly.

While reading this manual, remember:

**▲WARNING** Indicates a strong possibility that serious injury or death may result if instructions are not followed.