

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

| ITEMS | FREQUENCY | Whichever comes first | | INITIAL | REGULAR | | Refer to page |
|-----------------------------------|-----------|-----------------------|------|---------|---------|---------|----------------|
| | | ↻ | mi | 100 | 600 | 1200 | |
| | | | km | 150 | 1000 | 2000 | |
| | | | NOTE | HOURS | 20 | 100 | |
| * FUEL LINE | | | | | I | — | |
| * THROTTLE OPERATION | | | | | I | 108 | |
| * CARBURETOR CHOKE | | | | | I | 114 | |
| AIR CLEANER | (NOTE 1) | | | C | C | 109–112 | |
| AIR CLEANER HOUSING DRAIN TUBE | (NOTE 2) | | | I | I | 113 | |
| SPARK PLUG | | | | | I | 126–127 | |
| * VALVE CLEARANCE | | | | I | I | I | 128 |
| ENGINE OIL | | | | R | R | R | 43, 117–122 |
| ENGINE OIL FILTER | | | | R | R | R | 120–122 |
| * ENGINE IDLE SPEED | | | | I | I | I | 115 |
| RADIATOR COOLANT | (NOTE 3) | | | | I | I | 44, 129–131 |
| * COOLING SYSTEM | (NOTE 2) | | | | I | I | 129–132 |

- I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.
C: Clean R: Replace
A: Adjust L: Lubricate